

OPERATING INSTRUCTIONS

the detent (kick-down) position, according to the gear engaged, will give the desired condition.

Engine Braking when descending steep hills is attained by using the brakes to reduce the road speed to below 60 m.p.h. (96 k.p.h.) when "L" may be selected. The transmission will instantly change to second gear and provide engine braking.

Driving on Soft Surfaces

If the rear wheels fail to grip due to snow, mud or sand, the car may be rocked backwards and forwards by alternately selecting "R" and "D2" with a small throttle opening.

Emergency Starting

The car may be push or tow started; pushing is recommended as it avoids the

danger of the car over-running the towing vehicle.

Allow the car to reach a speed of approximately 25 m.p.h. (40 k.p.h.) with the selector in "N". Switch on the ignition, set the mixture control, and select "L" to enable the engine to be started through the rear wheels.

Towing must be accomplished with the selector lever in "N," provided the transmission is operating satisfactorily and the fluid level is correct. If the transmission is defective, the propeller shaft must be disconnected or the rear wheels lifted.

DO NOT SELECT "P" OR "R" WHEN THE CAR IS IN MOTION.